



small GW / Dropper paint holders for Small Paint Stations

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Pictures show GW version. Dropper is the same assembly, just taller.

Sheets:

GW: SG-05, SG-06

Dropper: SD-06, SD-07

One on each sheet

Use sidewalls with one tab on top.

The ones on the sheets with 2 tabs on top are for the large paint holder (one on each sheet).



The "Bones" are to connect units to each other instead of the water pot holders. No glue.

Sidewalls with one tab on top


1



1 the pieces that need to be glued together.

Assemble twice the same way

2



2 The tabs on the side towards the low front piece.
First glue the paint holder into the slits of the front and back walls.

3



Don't let glue come out anywhere.

3 then glue in the sidewalls. Ensure right angles

4



4 Glue in the bottom plate. The front and back tabs stick out on the bottom, which is correct.

Tip: During glue drying use vice grips and insert the paint holders into the bottom plate to ensure right angles / fit.