



large GW paint holder for Small Paint Station

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.


Sheets: SG-03,04

**One side wall on each
sheet: SG-05, SG-06**


Steps 2 to 4 are only if you have the LED lamp.

Use sidewalls with two tabs on top.

(one on each sheet of the small paint holders)



1 the pieces that need to be glued together.



2 IF YOU HAVE THE LAMP ONLY: the pieces that need to be glued together for the lamp holder. They are on the sheet for the lamp (LSA).



3 IF YOU HAVE THE LAMP ONLY: glue 3 of the keyhole plates on top of each other. Ensure that, on the long side, they are alternating between 2 tabs, then 1 tab, then 2 tabs again. Now glue this into the slots of the small side plates. Very exactly, and fully inserted. Flat sides facing the same direction. **No glue inside the keyholes! The keyholes have to line up perfectly!**



4 IF YOU HAVE THE LAMP ONLY: Glue this into the slots of the back wall, visible tabs facing downwards.

Use sidewalls with two tabs on top.
(one on each sheet of the small paint holders)

5



5 glue the paint holder into the front and back walls. Ensure right angles.

(please note the paint holder looks a bit different than in the picture, due to the lamp holder)

6



6 glue the 4 rounded off pieces into the slits of the paint holder from the top, all the way. Ensure right angles.

The brush holder can be stored here.


6 paints can be stored in the tool box during transport.

7



7 Glue on the side walls and the bottom plate. Ensure the bottom tabs from the little holders (**step 4 & 6**) go into the slits of the bottom plate.

8



8 Lastly, glue in the short strip with 3 tabs into the 3 slots at the bottom from below. Careful not to break it.

Tip: During glue drying use vice grips and insert the paint holders into the bottom plate to ensure right angles / fit.

Don't let glue show anywhere.