




large low storage unit for Ultimate version

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Sheets: USA1 & USA2



1 the pieces that need to be glued.

Sidewalls with 3 tabs on top



2 glue together the small keyhole plate and the 2 key protector plates. Do this twice. Ensure right angles.




3 Glue these 2 units into the slots of the back wall.



4 Glue the back wall onto the bottom plate. Ensure the little keyhole plates are glued onto the bottom with no space. Make sure there is no glue in the key holes and that they are exactly matching!



5 glue on the sidewalls, then the front wall. Sidewalls only fit the proper way around. Ensure right angles.



6 the front and side walls stick out on the bottom, which is correct. Glue the small strip with 3 tabs into the 3 slits from below. Careful not to break it.



7 use the dividers as needed, no glue.

Don't let glue come out anywhere.

Tip: During glue drying use vice grips and insert the paint holders into the bottom plate to ensure right angles / fit.

Remaining parts of USA2 are for small storage box – Ultimate & connectors