



Small Dropper stepped module – Large & Ultimate

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

NOTE: This is one of the most complicated units. Take your time!

Small stepped modules: build them twice.


Assemble the small stepped modules first, before doing the large one.

CAUTION: for the small stepped modules, there are left and right ones.


Ensure that during assembly, the hole for the drawer is once on the left, and once on the right.
The back walls and large bottom plates need to be mirrored during assembly for this to work.

SMALL: 2 times
Sheets: DSS1, DSS2


SMALL





Group 2



Group 3



Group 1



the pieces to be glued. Best to work in the indicated groups.

Work swiftly, so you can finish before the glue dries, so you can make adjustments.

mirrored



2




**Step 2 mirrored
for second module!**

1 Group 1: first glue in the bottom into the slits of the two walls as shown.

2 Group 1: then glue this into the slits of the large bottom plate.

3



4



3-4 Group 2: glue these 4 pieces together as shown. The narrow back plate needs to show up

5



6



5 Group 3: glue the 3 pieces together. The one with paint holes to the front, the one with no holes towards the back.

6: Glue in the paint holder with brush holes into the top slits of the back plate, and the slim brush holder into the middle slits.

7



8



7 glue the unit from **group 3** into the lowest slits of the back wall.

8 now glue in the units from **Group 1-2** into the slots of the closed sidewall. Group 1 at the bottom, group 2 slightly below the center. Work very fitting! **Insert fully into the slots!**

6 to 10 mirrored for second module!

9



9: now glue in the **back wall and group 3**
Work very fitting! The back wall sticks out at the bottom, this is correct.

Insert fully into the slots!

10



10: Now glue on the open sidewall. Best to work from top to bottom. Take your time, it can be a bit tedious.

Ensure right angles!

Insert fully into the slots on both sides!

**Don't let glue show anywhere. Use vice grips during glue drying time.
Ensure right angles.**

Tip: Insert into the bottom / middle plate during glue drying time so that everything fits together.