




Large Dropper drawers

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Sheets: DDL1, DDL2



1 Lower drawer: the pieces to be glued.

Upper and lower drawers. The lower drawer has the slightly longer pieces



2 Lower drawer: glue the 2 little pieces into the slits by the keyholes as shown on both sides. The small tab sticks out on the narrow side.



3-5 lower drawer:


Glue together from bottom, 2 sides, back and front walls.

Make sure the tabs from step 2 go into the holes of the back and side walls.



The "Bones" are to connect units to each other. No glue.

6



Large Upper Drawer:

6 Upper drawer: the pieces to be glued.

7




7 upper drawer: first glue on the front wall (with elongated slit) into the slits of the paint holder. Then glue on the bottom plate to the front wall. Ensure right angles.

8



8 glue on the side pieces. They only fit in one way. On each side, one tab sticks out. This is correct.

9



9 Glue on the back wall and the 2 narrow strips at the bottom of the back at a right angle and the rounded off side to the center.

Tip: Insert upper drawer into the lower one during glue drying time so that everything fits together. They are fitting snugly.