



War Mage Games

all your gaming needs



Large Dropper stepped module – Large & Ultimate

READ General Instructions FIRST!


TIP: Most pieces fit together without glue. Do a test run first, before gluing.

NOTE: This is the most complicated unit. Take your time!

LARGE:

Sheets: DSL1, DSL2, DSL3

LARGE:



1 the pieces to be glued. Best to work in the indicated groups.

Work swiftly, so you can finish before the glue dries, so you can make adjustments.

1




1 Group 1: first glue in the bottom into the slits of the two walls as shown.

2



2 Group 1: then glue this into the slits of the large bottom plate.

3



3-4 Group 2: glue these 4 pieces together as shown. The narrow back plate needs to show up

4




5



5 Group 3: glue the 3 pieces together. The one with paint holes to the front, the one with 2 keyholes towards the back.


6



If you don't have a lamp, leave out steps 6 to 9

6: the pieces of group 4

7



Do step 7-8 twice, but mirrored



7 Group 4: glue 4 of the keyhole plates on top of each other. Ensure that, on the long side, they are alternating between 1 tab, then 2 tabs, then 1 tab, then 2 tabs again. **No glue inside the keyholes! The keyholes have to line up perfectly!**


8



8 Group 4: Now glue this into the slots of the small plate. Very exactly, and fully inserted. Flat sides facing the same direction. **Do this twice, but mirrored.**




9 Group 4: glue these 2 small groups into the slits in the paint holder. Visible tabs facing to the back and outside.



10 Group 4: glue the unit from the previous steps (if no lamp: the plate with paint holes and brush holes) into the slits of the back wall. Very exactly, and fully inserted! This can be a bit tedious. Also glue in the long piece with brush holes into the lower slits of the back wall.



11: now glue in the units from **Group 1-4** into the slots of one sidewall. Group 1 at the bottom, group 2 slightly below the center, group 3 above the center and together with group 4. Work very fitting! **Insert fully into the slots!**



12: Now glue on the other sidewall. Best to work from top to bottom. Take your time, it can be a bit tedious.

Ensure right angles!

Insert fully into the slots on both sides!

Lastly, glue in the short strip with 3 tabs into the 3 slots at the bottom from below. Careful not to break it.

Don't let glue show anywhere. Use vice grips during glue drying time. Ensure right angles.

Tip: Insert into the bottom / middle plate during glue drying time so that everything fits together.