



small / large low GW paint holders for Ultimate version

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Sheets: UGS1 & UGS2

One on each sheet

Sidewalls with one tab on top

1



1 the pieces that need to be glued together.

Assemble twice the same way

2



2 The tabs on the side towards the low front piece. First glue the paint holder into the slits of the front and back walls.

3



Don't let glue come out anywhere.

4



Tip: During glue drying use vice grips and insert the paint holders into the bottom plate to ensure right angles / fit.

4 then glue in the sidewalls. Ensure right angles

4 Glue in the bottom plate. The front and back tabs stick out on the bottom, which is correct.

Remaining parts of UGS1 & UGS2 are for middle / upper plate.

Additional steps for the large low GW holder:


Sheets: UGA1 & UGA2

5



5 For the large paint holder, during step **3 and 4** glue in the 2 keyhole plates fitting into the inside corners. The little tabs go into the side & back walls. Make sure there is no glue in the key holes and that they are exactly matching!

6



6 For the large paint holder, glue the small strip with 3 tabs into the 3 slits from below. Careful not to break it.

Remaining parts of UGA2 are for small storage box – Ultimate & connectors