

Small Dropper stepped module Large & Ultimate

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

NOTE: This is the most complicated unit. Take your time!

SMALL: 2 times
Sheets: DSS1, DSS2


Small stepped modules: **build them the same way twice.**

Assemble the small stepped modules first, before doing the large one.



CAUTION: for the small stepped modules, there are left and right ones.

Ensure that during assembly, the hole for the drawer is once on the left, and once on the right. The back walls and large bottom plates need to be mirrored during assembly for this to work.


Mirrored !



SMALL:




Group 1



Group 2



Group 3



1 the pieces to be glued.
Best to work in the indicated groups.
Work swiftly, so you can finish before the glue dries, so you can make adjustments.

I

1 Group 1:

first glue in the bottom
into the slits of the two
walls as shown.






2 Group 1: then glue this into the slits of the large bottom plate.



Step 2 mirrored for second module!

3



4



3-4 Group 2:

glue these 4 pieces together as shown. The narrow back plate needs to show up

5 Group 3:

glue the 3 pieces together. The one with paint holes to the front, the one with 2 no holes towards the back.



6



6: Glue in the paint holder with brush holes into the top slits of the back plate, and the slim brush holder into the middle slits.

**Steps 6 to 10
mirrored for second
module!**

7



7 glue the unit from **group 3** into the lowest slits of the back wall.



8: now glue in the units from **Group 1-2** into the slots of the full sidewall.

Group 1 at the bottom, group 2 slightly below the center.

Work very fitting!

Insert fully into the slots!



9: now glue in the **back wall and group 3** Work very fitting! The back wall sticks out at the bottom, this is correct.

Insert fully into the slots!

10



10: Now glue on the open sidewall. Best to work from top to bottom. Take your time, it can be a bit tedious.

Ensure right angles!

Insert fully into the slots on both sides!

Don't let glue show anywhere. Use vice grips during glue drying time. Ensure right angles.

Tip: Insert into the bottom / middle plate during glue drying time so that everything fits together.

©www.WarMage.de

Industriestraße 24 | 27751 Delmenhorst | Germany

All rights reserved. All designs copyrighted.

Reproduction, also partial, not permitted.

This is not a toy. Recommended for ages 14 & up