

handgrip assembly information

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Sheets:

Small Dropper: SD-01, 02

Small GW: SG-01, 02

Large: LV-01, UV-02,03

Ultimate: UV-01, 02,03

Important:

Assemble the handgrips first, before gluing the other large plates together. Otherwise it will not work anymore. The hand grips just fit through the holes. Take some time and don't use force.

Follow the steps in the instructions exactly; everything will only fit in this exact order!

Read entire instructions first before beginning assembly!

**Small Paint Stations and
Ultimate-to-Small adapter:**

Do steps 13 to 17 **BEFORE step 1 to 12!**



1 the first pieces you need. The plate with the Warmage logo. Also this one has the custom engraving.

2

2 start left! Guide one handle piece through the bottom into the hole.

Do this at an angle, so the corners fit. Do not yet insert into the other hole.



3-4 Now do the same with another handgrip, through the same hole. The first one has to be all the way at the edge to fit the second one. Glue both together with glue everywhere.

3



4




5-6 now do the same on the other side. The whole thing can be a bit tedious, take your time, so the pieces don't break.




7-8 Now guide all pieces into the opposite holes and glue all 4 pieces together with plenty of glue and line them up so they are all at the same height.

Glue the little **square** plates into the slits through all four layers. Ensure everything is straight and the keyhole parts trough the bottom of the plate (with glue). The other side will stick out 6mm, which is correct.



9


9 Then glue on the next large plate from the bottom. Use lots of glue, also around the handgrip parts. Fully insert the plate.



The middle and large plate both have „top“ engraved on them, so you know which way to orientate them.

10

10 then glue this to the large plate.



Ensure the slits for the shoulder strap line up. If not, invert the large plate.


Important:

Use vice grips during glue drying time. Minimal tolerances.


Ensure no glue is visible anywhere.

11-12 glue two more little keyhole plates to the keyholes of the handgrip, so that the other side of the handgrip is covered (everything in one line)

Ensure all keyholes are oriented the same way, line up perfectly and there is no glue inside the keyholes!




13-14 glue two of the long plates fittingly on top of each other. **There are longer ones and shorter ones. Glue them together with the same length.** Glue these with **plenty** of glue into the slits of the large plate from the side with the keyholes. They only fit in one way and on one side. Long ones on top, short ones at the bottom side.




15-16 glue the 4 T-shaped pieces into the slots at the outside with plenty of glue on both sides. (from the center to the edge). These fit VERY tightly. If they don't go in by hand, use a soft hammer or the likes to gently tap them in place from the edge. Do not break the upper part of the slots.

15



16





Important:

Test that the handgrip fits on the assembled paint station. Slide over top and bottom straight from the front.

They fit snugly over the station.

Use vice grips during glue drying time. Ensure right angles.

Minimal tolerances! Ensure no glue is visible anywhere.



18 Glue the foam fittingly around the handgrip and attach the shoulder strap on both sides through the small slits.

©www.WarMage.de

Industriestraße 24 | 27751 Delmenhorst | Germany

All rights reserved. All designs copyrighted.

Reproduction, also partial, not permitted.

This is not a toy. Recommended for ages 14 & up