

# Large Dropper stepped module

## Large & Ultimate

**READ General Instructions FIRST!**

**TIP:** Most pieces fit together without glue. Do a test run first, before gluing.

**NOTE:** This is the most complicated unit. Take your time!

**LARGE:**

**Sheets: DSL1, DSL2, DSL3**

**LARGE:**

Group 3

Group 2

Group 4

Group 1

1 the pieces to be glued.  
Best to work in the  
indicated groups.  
**Work swiftly, so you can  
finish before the glue  
dries, so you can make  
adjustments.**

I

## 1 Group 1:

first glue in the bottom into the slits of the two walls as shown.




2

**2 Group 1:** then glue this into the slits of the large bottom plate.



3



4



### 3-4 Group 2:

glue these 4 pieces together as shown. The narrow back plate needs to show up


### 5 Group 3:

glue the 3 pieces together. The one with paint holes to the front, the one with 2 keyholes towards the back.





6




6:

the pieces of **group 4**

If you don't  
have a lamp,  
leave out steps  
6 to 9

7




**7 Group 4:** glue 4 of the keyhole plates on top of each other. Ensure that, on the long side, they are alternating between 1 tab, then 2 tabs, then 1 tab, then 2 tabs again. **No glue inside the keyholes! The keyholes have to line up perfectly!**

**Do step 7-8 twice, but mirrored**



8



### 8 Group 4:


Now glue this into the slots of the small plate. Very exactly, and fully inserted. Flat sides facing the same direction.

**Do this twice, but mirrored.**

9


## 9 Group 4:

glue these 2 small groups into the slits in the paint holder. Visible tabs facing to the back and outside.



**10 Group 4:** glue the unit from the previous steps (if no lamp: the plate with paint holes and brush holes) into the slits of the back wall.

Very exactly, and fully inserted! This can be a bit tedious. Also glue in the long piece with brush holes into the lower slits of the back wall.






**11:** now glue in the units from **Group 1-4** into the slots of one sidewall.

Group 1 at the bottom, group 2 slightly below the center, group 3 above the center and together with group 4.

Work very fitting! **Insert fully into the slots!**

12



**12:** Now glue on the other sidewall. Best to work from top to bottom. Take your time, it can be a bit tedious.

**Ensure right angles!**

**Insert fully into the slots on both sides!**

**Don't let glue show anywhere. Use vice grips during glue drying time. Ensure right angles.**

Tip: Insert into the bottom / middle plate during glue drying time so that everything fits together.

Lastly, glue in the short strip with 3 tabs into the 3 slots at the bottom from below. Careful not to break it.

©www.WarMage.de

Industriestraße 24 | 27751 Delmenhorst | Germany

All rights reserved. All designs copyrighted.

Reproduction, also partial, not permitted.

This is not a toy. Recommended for ages 14 & up