Setup Home Expansion Modules

READ General Instructions FIRST!

CAUTION: Liquids

The material for the kits is MDF, which is made from wood.

Do not let any liquids soak into the material!

Always completely empty and dry off the water pots and wet palette before transport.

Ensure all paints are properly closed.

If the surface gets wet, wipe the liquid away quickly.



You can set up modules on top of the stackable modules, up to 4 high.

Also the Portable Paint Station modules can be integrated. Narrow modules also fit on top of large stackable modules.

Connect them all with the "bones" on the sides.

All Home Expansion Modules have little holes in the back walls. Through these, you can screw them to the wall for additional support. DO NOT HANG THEM ON THESE! They are not designed to hang, but to stand. Screwing to the wall is optional / adds more support and stability, especially when stacking more than 2 high.

