



Lamp holder – Large & Ultimate Stations

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

Sheets: separate sheet or with brush holder



1 the pieces to be glued.

Do everything twice.



2 glue in the little pieces into the plate with the rounded off corners. Ensure right angles, and that the long side of these faces the short side of the plate.


Screws & nuts in bag with agitator balls



3 glue together very fittingly two of the hoops.



4 then glue these hoops into the plate with the shorter slit.



5 then glue the plate with the longer slit to the bottom. **The little hole is where you screw on the metal holder of the lamp, from the bottom. Use the supplied screws and nuts. Screw into the metal holder, nut on top.**




6 glue **3** of the open plates very fittingly onto a plate with the little keyhole. All holes oriented the same way. Put lots of glue between each layer.



7 then glue a closed plate with larger hole (same orientation as open ones) very fittingly on top of the open plates. **DO NOT PRESS TOGETHER!** Here you want to ensure that, due to the glue, there is a minimal gap between the layers, so that the locking keys can be easily inserted.

DO NOT PRESS THIS UNIT TOGETHER! No glue in the key holes or slot for locking keys!


8



8-9 Lamp Setup:


1. Insert the arm holders onto the key from the back and turn it 90 degrees to lock it in place. You can do this at several height positions.
2. Then insert this key into the holder in the large stepped paint unit, and lock in place by turning it 90 degrees.
3. Slide the lamp holders over the front key (with little indentation in the top) to the desired position.
4. Insert the front key into the arm holder. Lock it in place with the little lock piece.
5. Clip the lamp onto the metal clips.
6. Attach power cord to lamp. You may need a power plug adapter for your country. Power cord can be on either side. Use plastic cap to protect lamp plug on the other side.

9



The lamp can move around a bit.
This is normal. It is quite sturdy, but
do not put weight on it.

10



10 Lamp storage:

You can store the lamp and all other pieces of the lamp in the wide part of the upper tool box.

Store the power cord in the water pot tool box (cable inside water pot is best)