

Lamp holder – Small Stations

READ General Instructions FIRST!

TIP: Most pieces fit together without glue. Do a test run first, before gluing.

**Sheets:
SL-01 or LSA**

**Screws & nuts
in bag with
agitator balls**



1 the pieces to be glued.

Assemble arms same way as the locking keys.

See setup guide for lamp setup.



2 glue in the little pieces into the plate with the rounded off corners.

Ensure right angles, and that the long side of these faces the short side of the plate.




3 glue
together three
of the hoops
very fittingly .

4



4 then glue these hoops into the plate with the shorter slit.

5



5 then glue the plate with the longer slit to the bottom.

The little holes are where you screw on the metal holders of the lamp, from the bottom. Use the supplied screws and nuts. Screw into the metal holder, nut on top.

6



6 glue **3** of the open plates very fittingly onto a plate with the little keyhole.

All holes oriented the same way. Put lots of glue between each layer.

7



DO NOT PRESS THIS UNIT TOGETHER! No glue in the key holes or slot for locking keys!

7 then glue a closed plate with larger hole (same orientation as open ones) very fittingly on top of the open plates. DO NOT PRESS TOGETHER!

Here you want to ensure that, due to the glue, there is a minimal gap between the layers, so that the locking keys can be easily inserted.